
### Underground Mining Methods



Stanley C. Suboleski Virginia Tech June 23, 1999

#### Two Main Methods

- Room & Pillar
  - Mostly with continuous miners
- Longwall
  - Develop longwall panels with room & pillar using continuous miners
- About 10% of underground production still comes from drilling & blasting
- Total underground output = 421mt (1997 data)

## FIRST, MUST ACCESS THE MINE

- Drift (Adit)
  - Seam outcrops, access from ground level
- Slope
  - Drive incline in rock at up to 16 degrees
  - Allows belt haulage
- Shaft
  - Use: elevators/skips, for: people/coal
  - Use shaft if >1500 feet, economics dictate

### LIKE A CITY, OR LARGE BUILDING, SERVICES MUST BE PROVIDED

- Transport people (rail, rubber tired)
- Transport supplies (materials / maintenance)
- Transport product (coal)
- Support roof
- Provide electrical power
- Provide fresh air (& suppress dust)
- Provide fresh water
- Get rid of waste water
- Dispose of trash

#### ROOM & PILLAR

- Mine "streets & avenues" (entries and crosscuts)
- Leave pillars to support roof (may mine later)
  - Designed by formula
- Plan view-looks like city with "greenbelts"
  - "Greenbelts" are large barrier pillars left to separate work areas
- Use continuous miner

#### MINE PLAN

- Main entries (7-9 openings)
- Submains (5-7 openings)
- Panels (panel entries, butt entries)
- Rooms (at times)
- Openings limited to 20-ft width
  - Openings serve as air ducts and travelways
  - Return air is isolated from fresh air, two escapeways must be provided from face
- Longwall panels are solid coal blocks, usually 1000 ft by 10,000 ft, accessed by "gate" roads

### ALL SERVICES EXIST TO SUPPORT MINING AT FACE

- Continuous miner rips coal, using tungsten carbide bits - miner mines at 4-25 t/m and conveys coal into shuttle cars
- Shuttle cars are electric (cable) "trucks" which haul for up to 600 feet or so (usual = 300-400 feet)
  - Haul to feeder-breaker which acts as surge bin/crusher and feed coal onto belt
  - Hold 3-25 tons/load, depending on seam thicknesss and amount of rock mined

## FEEDER-BREAKER FEEDS COAL ONTO BELT CONVEYORS

- Conveyors transport coal to surface or into skips for shaft access
  - Usual sizes 42" to 72"
  - Speeds 500 800 fpm
- Longwall requires largest conveyors
  - 54"-60" usual from face

## ROOF BOLTS INSTALLED BY ROOF BOLTING MACHINE

- Roof supported by inserting reinforcing rods
- No one may work under unsupported roof
  - Cut depths limited to position of shuttle car operator (35' to 40' with remote control miner)
- When miner place changes, bolter moves in
  - Bolt 3-6 min/row or 0.75-1.50 min/ft
  - Use two bolter operators, twin-boom bolter
- A few operations attach bolters to miners, bolt as they advance

#### **ROOF SUPPORT**

- Insert bolts into the roof on regular pattern (3'-8' length, usually)
  - 4' x 4' or 5' x 5' most common
- Either "glue" (resin) a re-bar bolt in, or
- Use expansion bolt anchors or
- Glue in the anchor only
  - Anchors allow pre-tensioning of bolts

## ROOF BOLTS GENERALLY WORK WELL

- Form "reinforced" rock, strong beam
- Or, may "hang" weak rock from stronger overlying rock layer
- Roof fall fatalities are now at 8 -12 per year
  - Half are in violation of the law, under nonbolted roof
  - Roof fall fatalities exceeded 100 per year around 1970

#### **VENTILATION**

- Provides oxygen, dilutes methane & dust
  - Methane explosive when at 5-15% concentration
- Most coninuous miners have dust scrubber
  - Draw air into ducts at front of miner
  - Efficiency up to 96-97%
- Air directed to working face with brattice cloth (plastic curtains)
- Alternatively, hang tubing & use fan to draw air to face

#### **VENTILATION**

- Fresh air ventilates one face only, then it is "return" air
  - Separate air streams with concrete block walls or "stoppings"
- Maximum allowable methane content is 1%
- Control major flow with adjustable doors in airways ("regulators")

#### PRODUCTION RATES

- 150 400 ft/shift usual, tonnage depends on seam thickness
  - 500 2000 tons/shift (usual)
- New miners load at 10 25 tpm
- Most continuous miners load only 60-120 min/shift
  - Load only 12
  - 10-25% of shift time

#### LONGWALL

- More nearly continuous method
- Analogous to "deli meat slicer" (shearer)
- Shearer mounted on chain conveyor
  - Coal cut falls onto conveyor
- Width of face usually 850 1100 ft
  - Depth of slice is 30 42 inches
- Behind face supported for 20' or so by steel supports - each 1.50 or 1.75 m wide
  - Each support holds up to 600-1200 tons
- Supports connected to conveyor
  - By pushing, lowering & pulling can walk conveyor and selves forward

#### LONGWALL

- Panels (solid block of coal)
  - Usually 850' 1100' wide & 7500' 15,000'long
  - Contain 1.5 4 mm tons per panel
- Shearers cut at 35 65 t/min (2000-4000 tph)
- Output per year = 2 6 mm tons
- $\bullet$  6,000 20,000 t/day (max = 40,000)
- Cut 200-500 min/day
  - 20% 45% of time (???)

#### LONGWALL

- Capital intensive
  - \$30M for face equipment only
  - \$50-80M additional for mine / processing
- Require large, regularly shaped reserve
  - 50M ton minimum
  - Prefer 100-200M tons
- Mine-specific design / limited ability to move to other reserves

# CONTINUOUS MINER SUMMARY

- Capital for section is \$3-5 million
- Flexible, can move readily to other reserves
- One longwall usually requires three continuous miners for development
- Annual output for miner section is 0.3 0.8 million tpy

#### **ENVIRONMENTAL**

- Longwall strata caves behind supports
  - Surface subsides to maximum of 50-70% of seam thickness
  - "Tilt" area may damage structures, so must provide special support methods at the structures to minimize damage
  - Subsidence trails face position by a few days to a week or two, about 95% occurs in a few weeks

#### LONGWALL SUBSIDENCE

- Ground water flow is altered
- Some wells lose flow, temporarily or permanently; a few gain
- May need to drill wells deeper
- Connection from near surface to mine is possible if depth to aquifer is less than 40 x seam thickness (240 ft for 6-ft seam)

#### **SUMMARY**

- Longwall (45% of UG output from only 60 faces -- average of 3 million tpy each)
  - High output, high capital
  - Low operating cost, 70-80% (?) reserve recovery
  - Low flexibility
- Continuous Miners
  - Medium output, low-medium capital
  - Moderate operating cost, 40-60% reserve recovery
  - High flexibility

#### **SUMMARY**

- Can use underground methods in +100 ft of overburden (actual minimum depth depends on whether strip ratio favors surface mining)
  - Roof subject to surface cracks when shallower
- Use longwall in large, thick (mine 6-ft min.), regularly-shaped reserves
  - Only economic method if seam is >1500 ft deep
- Else, use continuous miner and room & pillar
- While best walls far exceed cm productivity, on average, tons per manhour are close



Longwall mining machines have revolutionized underground coal mining, enhancing safety and productivity.

